



Quench Detection System Commands Reference Manual



CAEN ELS s.r.l.



Contents

1 Document Revisions	3
2 QDS Commands List	4
2.0.1 Preliminary Notes	4
2.1 Basic commands	5
2.1.1 VER command	5
2.1.2 HELP command	6
2.1.3 TEMP command	7
2.1.4 IFCONFIG command	8
2.2 QDS Commands	10
2.2.1 GET command	10
2.2.2 RNG Command	12
2.2.3 WIN Command	14
2.2.4 THR Command	16
2.2.5 ENA Command	18
2.2.6 STR Command	20
2.2.7 PRS Command	21
2.2.8 USRCORR Command	22
2.2.9 FLS Command	24
2.2.10 DFLT Command	26
2.2.11 SAVE Command	27
2.2.12 LOAD Command	28
2.2.13 DEVID Command	29
2.2.14 LOGGER Command	30
2.2.15 TRGOUT Command	31
2.3 QDS Errors	32
2.3.1 Errors list	32



1 Document Revisions

Document Revision	Date	Requirements
0.1	September 8th, 2021	First Release
1.2	December 4th, 2025	Release 1.1.08
1.3	April 28th, 2026	Release 1.1.09





2 QDS Commands List

2.0.1 Preliminary Notes

Numbers are transmitted in ASCII data format.

All commands are terminated with character `\r\n`.

Write commands respond with `ACK` or `NAK:<error_code>`. At the end of document there is a list of error codes with description.

Read commands respond with an echo.

Command are formatted as:

`<COMMAND>`, `<COMMAND>:<OPTION>` or `<COMMAND>:<PARAMETER>:<OPTION>`.





2.1 Basic commands

2.1.1 VER command

Reads device model and version.

R / W	Command	Response
R	VER	VER:QDS:<version>:<info_1>:<info_2>:...

Example:

VER

#VER:QDS:1.0.00:+/-20V +/-20mV





2.1.2 HELP command

Reads commands list.

R / W	Command	Response
R	HELP	<command>\t<description>
R	?	<command>\t<description>

Example:

```
HELP
#GET           Gets single reading
#RNG           Voltmeter input range
#ENA           Channels enabled
#WIN           Time window size
#THR           Channel thresholds
#STR           Quench status
#PRS           Persistent switch status
#USRCORR      User correction of voltages
#FLS           Full scale input
#DFLT          Restores default parameters
#SAVE          Stores current configuration
#LOAD          Configuration on startup
#VER           Displays model and version
#TEMP          Gets system temperature
#IFCONFIG      Displays interface config and stats
#LOGGER        Data logger
#TRGOUT        Trigger out
#HELP          Displays commands
#?             Displays commands
```



2.1.3 TEMP command

Reads internal system temperature.

R / W	Command	Response
R	TEMP	TEMP:<value>

Parameters:

value	Type	Unit
System temperature	int	°C

Example:

```
TEMP  
#TEMP : 32
```





2.1.4 IFCONFIG command

Reads interface configuration and statistics.

R / W	Command
R	IFCONFIG
R	IFCONFIG:TCP
R	IFCONFIG:LINK
R	IFCONFIG:ICMP

Example:

```
IFCONFIG
#  MAC: 00:12:5e:01:00:00
#  IP address: 192.168.1.201
#  Netmask: 255.255.255.0
#  Gateway: 192.168.1.1
#  Rx bytes: 4575482 (54730 frames), TX bytes: 2641 (35
    frames)
#  Errors:
#    Frame errors: 0, Alignment errors: 0, In errors: 0
IFCONFIG:TCP
#TCP stats:
#    xmit: 17
#    recv: 36
#    fw: 0
#    drop: 0
#    chkerr: 0
#    lenerr: 0
#    memerr: 0
#    rterr: 0
#    proterr: 0
#    opterr: 0
#    err: 0
#    cachehit: 0
IFCONFIG:LINK
#Link stats:
#    xmit: 45
#    recv: 62682
#    fw: 0
#    drop: 0
```



```
#      chkerr: 0
#      lenerr: 0
#      memerr: 0
#      rterr: 0
#      proterr: 0
#      opterr: 0
#      err: 0
#      cachehit: 0
IFCONFIG:ICMP
#ICMP stats:
#      xmit: 0
#      recv: 0
#      fw: 0
#      drop: 0
#      chkerr: 0
#      lenerr: 0
#      memerr: 0
#      rterr: 0
#      proterr: 0
#      opterr: 0
#      err: 0
#      cachehit: 0
```





2.2 QDS Commands

2.2.1 GET command

Reads single or all channels.

R / W	Command	Response
R	GET:<channel>:?	GET:<channel>:<value>
R	GET:?	GET:<value_ch1>:<value_ch2>:...:<value_ch34>

Parameters:

channel	Description
CH1	Physical channel 1
CH2	Physical channel 2
CH3	Physical channel 3
CH4	Physical channel 4
CH12	Differential channel CH1 - CH2
CH13	Differential channel CH1 - CH3
CH14	Differential channel CH1 - CH4
CH23	Differential channel CH2 - CH3
CH24	Differential channel CH2 - CH4
CH34	Differential channel CH3 - CH4

Channels order

CH1 : CH2 : CH3 : CH4 : CH12 : CH13 : CH14 : CH23 : CH24 : CH34

value / value_chx	Description
float number (scientific notation for GET:CHx:?, lowercase)	Voltage [V]
float number (not scientific notation for GET:?)	Voltage [V]
NA	Channel disabled

Example:

```
GET:CH1:?  
#GET:CH1:-3.854367e-01
```



GET:CH24:?

#GET:CH1:NA

GET:?

#GET:0.00042:-0.00123:0.00251:-0.00006:-0.00183:-0.00191:
0.00066:-0.00116:NA:-0.00257





2.2.2 RNG Command

Writes/Reads single or all channels range. If a channel threshold is higher than full scale value of new range, threshold is set to the full scale value.

R / W	Command	Response
W	RNG:<channel>:<value>	ACK
R	RNG:<channel>:?	RNG:<channel>:<value>
W	RNG:<value>	ACK
R	RNG:?	RNG:<value_ch1>:<value_ch2>:<value_ch3>:<value_ch4>

Parameters:

channel	Description
CH1	Physical channel 1
CH2	Physical channel 2
CH3	Physical channel 3
CH4	Physical channel 4

range	Input Full Range [V]
0 (default)	+/- 20
1	+/- 10
2	+/- 5
3	+/- 2.5
4	+/- 1.25
5	+/- 0.625
6	+/- 0.3125
7	+/- 0.15625
8	+/- 0.078125
9	+/- 0.390625
10	+/- 0.01953125

Example:

```
RNG : CH1 : 3  
#ACK
```

```
RNG : CH4 : ?
```



#RNG:CH4:7

RNG:5

#ACK

RNG:?

#RNG:7:5:8:0





2.2.3 WIN Command

Writes/Reads single or all channels time windows.

R / W	Command	Response
W	WIN:<channel>:<value>	ACK
R	WIN:<channel>:?	WIN:<channel>:<value>
W	WIN:<value>	ACK
R	WIN:?	WIN:<value_ch1>:<value_ch2>:...:<value_ch34>

Parameters:

channel	Description
CH1	Physical channel 1
CH2	Physical channel 2
CH3	Physical channel 3
CH4	Physical channel 4
CH12	Differential channel CH1 - CH2
CH13	Differential channel CH1 - CH3
CH14	Differential channel CH1 - CH4
CH23	Differential channel CH2 - CH3
CH24	Differential channel CH2 - CH4
CH34	Differential channel CH3 - CH4

Channels order

CH1 : CH2 : CH3 : CH4 : CH12 : CH13 : CH14 : CH23 : CH24 : CH34

value / value_chx	Default	Type	Min	Max	Unit
Time window	10	int	10	500	ms

Example:

```
WIN:CH2:100
```

```
#ACK
```

```
WIN:CH24:?
```

```
#WIN:CH24:500
```



WIN:50

#ACK

WIN:?

#WIN:500:100:20:50:10:250:100:300:500:10





2.2.4 THR Command

Writes/Reads single or all channels thresholds.

R / W	Command	Response
W	THR:<channel>:<value>	ACK
R	THR:<channel>:?	THR:<channel>:<value>
W	THR:<value>	ACK
R	THR:?	THR:<value_ch1>:<value_ch2>:...:<value_ch34>

Parameters:

channel	Description
CH1	Physical channel 1
CH2	Physical channel 2
CH3	Physical channel 3
CH4	Physical channel 4
CH12	Differential channel CH1 - CH2
CH13	Differential channel CH1 - CH3
CH14	Differential channel CH1 - CH4
CH23	Differential channel CH2 - CH3
CH24	Differential channel CH2 - CH4
CH34	Differential channel CH3 - CH4

Channels order

CH1 : CH2 : CH3 : CH4 : CH12 : CH13 : CH14 : CH23 : CH24 : CH34

value / value_chx	Default	Type	Min	Max	Unit
Threshold	20 (physical chs) 40 (differential chs)	float	0	Full scale value (see FLS command) Sum of physical channels full scale value (for differential channels)	V

Example:

```
THR : CH1 : 1
#ACK
```



THR:CH14:?

#THR:CH24:2.50000

THR:3

#ACK

THR:?

#THR:4.00000:1.00000:2.00000:2.40000:3.00000:
1.00000:1.00000:5.00000:3.50000:10.00000





2.2.5 ENA Command

Enables/Disables channel.

R / W	Command	Response
W	ENA:<channel>:<value>	ACK
R	ENA:<channel>:?	RNG:<channel>:<value>
W	ENA:<value>	ACK
R	ENA:?	RNG:<value_ch1>:<value_ch2>:...:<value_ch34>

Parameters:

channel	Description
CH1	Physical channel 1
CH2	Physical channel 2
CH3	Physical channel 3
CH4	Physical channel 4
CH12	Differential channel CH1 - CH2
CH13	Differential channel CH1 - CH3
CH14	Differential channel CH1 - CH4
CH23	Differential channel CH2 - CH3
CH24	Differential channel CH2 - CH4
CH34	Differential channel CH3 - CH4

Channels order

CH1 : CH2 : CH3 : CH4 : CH12 : CH13 : CH14 : CH23 : CH24 : CH34

value / value_chx	Description
ON (default)	Channel enabled
OFF	Channel disabled

Example:

```
ENA : CH3 : ON  
#ACK
```

```
ENA : CH13 : ?
```



#ENA : CH13 : OFF

ENA : ON

#ACK

ENA : ?

#ENA : OFF : OFF : OFF : OFF : OFF : OFF : OFF : OFF : OFF : OFF





2.2.6 STR Command

Reads/Resets status.

R / W	Command	Response
W	STR:RESET	ACK
R	STR:?	STR:0X<mask>

Parameters:

mask	Description	Type	Min	Max
Status	CH1 CH2 CH3 CH4 CH12 CH13 CH14 CH23 CH24 CH34	hex	0	3FF

channel	Quench event	No quench event
CH1 quench signal ON/OFF	0b1000000000 or 0x200	0b0 or 0x0
CH2 quench signal ON/OFF	0b0100000000 or 0x100	0b0 or 0x0
CH3 quench signal ON/OFF	0b0010000000 or 0x80	0b0 or 0x0
CH4 quench signal ON/OFF	0b0001000000 or 0x40	0b0 or 0x0
CH12 quench signal ON/OFF	0b0000100000 or 0x20	0b0 or 0x0
CH13 quench signal ON/OFF	0b0000010000 or 0x10	0b0 or 0x0
CH14 quench signal ON/OFF	0b0000001000 or 0x8	0b0 or 0x0
CH23 quench signal ON/OFF	0b0000000100 or 0x4	0b0 or 0x0
CH24 quench signal ON/OFF	0b0000000010 or 0x2	0b0 or 0x0
CH34 quench signal ON/OFF	0b0000000001 or 0x1	0b0 or 0x0

Example:

```
STR:RESET
```

```
#ACK
```

```
STR:?
```

```
#STR:0X80
```



2.2.7 PRS Command

Sets/Clears persistent switch.

R / W	Command	Response
W	PRS:<value>	ACK
R	PRS:?	PRS:<value>

value	Description
ON	Set persistent switch
OFF (default)	Clear persistent switch

Example:

PRS : ON

#ACK

PRS : ?

#PRS : OFF





2.2.8 USRCORR Command

Enables/Disables or write/read user correction or store values. Add user correction voltage to the acquired value.

R / W	Command	Response
W	USRCORR:<state>	ACK
R	USRCORR:?	USRCORR:<state>
W	USRCORR:RNG<r>CH<ch>OFFS:<v>	ACK
R	USRCORR:RNG<r>CH<ch>OFFS:?	USRCORR:RNG<r>CH<ch>OFFS:<v>
W	USRCORR:SAVE	ACK

- where *r*, *ch* and *v* stand for *range*, *channel* and *value* respectively.

Parameters:

state	Description
ON	User correction enabled
OFF (default)	User correction disabled

range	Description
0	+/- 20 V Full scale voltage
1	+/- 10 V Full scale voltage
2	+/- 5 V Full scale voltage
3	+/- 2.5 V Full scale voltage
4	+/- 1.25 V Full scale voltage
5	+/- 0.625 V Full scale voltage
6	+/- 0.3125 V Full scale voltage
7	+/- 0.15625 V Full scale voltage
8	+/- 0.078125 V Full scale voltage
9	+/- 0.0390625 V Full scale voltage
10	+/- 0.01953125 V Full scale voltage

channel	Description
CH1	Physical channel 1
CH2	Physical channel 2



channel	Description
CH3	Physical channel 3
CH4	Physical channel 4

value	default	Type	Unit
offset correction	0	float	V

Example:

USRCORR : OFF

#ACK

USRCORR : ?

#USRCORR : ON

USRCORR : RNG10CH2OFFS : -1.564598

#ACK

USRCORR : RNG8CH1OFFS : ?

#USRCORR : RNG8CH1OFFS : 2.682657

USRCORR : SAVE



2.2.9 FLS Command

Reads channel/range full scale. Differential channel full scale value is the sum of physical channel full scale values.

R / W	Command	Response
R	FLS:<channel>:?	FLS:<channel>:<value>
R	FLS:CH:?	FLS:CH:<value_ch1>:<value_ch2>:...:<value_ch34>
R	FLS:<range>:?	FLS:<range>:<value>
R	FLS:RNG:?	FLS:RNG:<value_rng1>:<value_rng2>:...:<value_rng34>

Parameters:

channel	Description
CH1	Physical channel 1
CH2	Physical channel 2
CH3	Physical channel 3
CH4	Physical channel 4
CH12	Differential channel CH1 - CH2
CH13	Differential channel CH1 - CH3
CH14	Differential channel CH1 - CH4
CH23	Differential channel CH2 - CH3
CH24	Differential channel CH2 - CH4
CH34	Differential channel CH3 - CH4

range	Available Full Scale Voltage [V]
0	20
1	10
2	5
3	2.5
4	1.25
5	0.625
6	0.3125
7	0.15625
8	0.078125
9	0.0390625
10	0.01953125



Example:

FLS:CH1:?

#FLS:CH1:2.500000

FLS:CH:?

#FLS:CH:20.00000:20.00000:20.00000:20.00000:40.00000:
40.00000:40.00000:40.00000:40.00000:40.00000

FLS:RNG6:?

#FLS:RNG6:0.312500

FLS:RNG:?

#FLS:RNG:20.00000:10.00000:5.00000:2.50000:1.25000:0.62500:
0.31250:0.15625:0.07812:0.03906:0.01953





2.2.10 DFLT Command

Restores default parameters.

R / W	Command	Response
W	DFLT	ACK

Parameter	Default value
Range	0
Time window [ms]	10
Enable	ON
Threshold [V]	20 (physical channel) 40 (differential channel)
User correction	OFF
Status	0x0
Logger	OFF
Logger time window [ms]	10
Trgout polarity	LOW
Persistent switch	OFF

Example:

```
DFLT  
#ACK
```



2.2.11 SAVE Command

Saves configuration: channels enabled, time windows, thresholds and user correction enable/disable. On startup range is always set to 0.

R / W	Command	Response
W	SAVE	ACK

Example:

```
SAVE  
#ACK
```





2.2.12 LOAD Command

Configuration to load on startup (default or user parameters).

R / W	Command	Response
R	LOAD:?	LOAD:<setting>
W	LOAD:<setting>	ACK

Parameters:

setting	Description
DFLT	Default setting
USER	User setting saved

Example:

```
LOAD:?  
#LOAD:DFLT  
  
LOAD:USER  
#ACK
```



2.2.13 DEVID Command

Configuration to load on startup (default or user parameters).

R / W	Command	Response
R	DEVID:?	DEVID:<dev_id>
W	DEVID:SAVE:<dev_id>	ACK

Parameters:

dev_id	Description
CELS	Default value Only 4 characters are allowed

Example:

```
DEVID:SAVE:QDS1  
#ACK
```

```
DEVID:?  
#DEVID:QDS1
```

```
DEVID:SAVE:ABCDE  
#NAK:96
```



2.2.14 LOGGER Command

Enables/Disables Logger and reads/writes Logger Time Window (in ms).

R / W	Command	Response
R	LOGGER:?	LOGGER:<value>
W	LOGGER:<value>	ACK
R	LOGGER:TW:?	LOGGER:TW:<tw>
W	LOGGER:TW:<tw>	ACK

Parameters:

value	Description
ON	Enables Logger
OFF (default)	Disables Logger

tw	Default	Type	Min	Max
Logger Time Window	1000 ms	int	100 ms	10000 ms (10s)

Example:

```
LOGGER:ON  
#ACK
```

```
LOGGER:?  
#LOGGER:ON
```

```
LOGGER:TW:100  
#ACK
```

```
LOGGER:TW:?  
#LOGGER:TW:100
```

```
LOGGER:TW:1  
#NAK:31
```



2.2.15 TRGOUT Command

Sets and reads trigger out polarity. This value is stored in the device's internal memory.

R / W	Command	Response
R	TRGOUT:POL:?	TRGOUT:POL:<polarity>
W	TRGOUT:POL:<polarity>	ACK

Parameters:

polarity	Description
LOW (default)	Polarity active low
HIGH	Polarity active high

Example:

```
TRGOUT:POL:?  
#TRGOUT:POL:HIGH
```

```
TRGOUT:POL:LOW  
#ACK
```

```
TRGOUT:POL:0  
#NAK27
```

```
TRGOUT:ON  
#NAK27
```



2.3 QDS Errors

2.3.1 Errors list

Code	Description
0	Invalid command
18	error_wrong_config
19	error_wrong_channel
20	error_wrong_enable
21	error_wrong_thr
22	error_wrong_range
23	error_wrong_usrcorr
24	error_wrong_timeWindow
25	error_wrong_status
27	error_wrong_trgout
31	error_wrong_logger_tw
96	error_wrong_dev_id